OVEN PARTS

For Models:GBD277PDB7, GBD277PDQ7, GBD277PDS7, GBD277PDT7
(Black) (Designer White) (Black Stainless) (Biscuit)

27" BUILT−IN ELECTRIC
DOUBLE OVEN
CONVECTION − UPPER OVEN
SELF−CLEAN (GOLD LINE)



Literature Parts

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models:GBD277PDB7, GBD277PDQ7, GBD277PDS7, GBD277PDT7
(Black) (Designer White) (Black Stainless) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1		Literature Parts
	LIT8300655	Installation Instructions
	LIT8300668	Use & Care Guide
	LIT4451887	Tech Sheet (Oven)
	LIT3191638	Safer Cooking Tips
	OVEN PARTS	
2		Trim, Side
	4450850	RH Black
	4450851	RH White
	4452122	RH Biscuit
	4450853	LH Black
	4450854	LH White
	4452123	LH Biscuit
		Screw
	8281236	Black Model
	4449041	White Model
	694091	Biscuit Model
3		Receiver, Hinge
	4455605	Left Hand
	4455606	Right Hand
4	4448520	Bumper, Door
6	4452200	Divider, Vent
	4449809	Screw
7	4455285	Top Chassis
	4449809	Screw
9	4452158	Tube, Vent
	3196176	Screw
10	4452165	Lens, Light
11	4452368	Light Assy, Rear
12	4452166	Bulb, Light
14	4455611	Frame, Front
	4449040	Screw
	4450118	Nut
15	4455381	Gasket, Door
19	4451477	Support, Insulation
	4449809	Screw
20	4451605	Cap, Spacer
21		Rail, Side
	4450581	Right
	4450582	Left
	4448444	Grommet
	4449154	Screw
24	4451896	Latch Assy
	4449809	Screw
25	4455641	Side, Chassis
		(R.H. & L.H.)
	4449809	Screw
26	4452233	Back, Chassis
	4449809	Screw
27		Liner, Oven
		(Not serviceable)
28	4452224	Solenoid
29	4455636	Sensor
	4449154	Screw
30	4452312	Switch, Micro N.C.
31	4451426	Switch, Micro
32	4451537	Spring, Latch
34	4452266	Vent, Center
37		Safety (TOD) Swtch
		Thermostat (temp)
	4452223	Upper Oven
	4451442	Lower Oven
	4449809	Screw
43	4455529	Base, Chassis
	4449809	Screw
49	4448933	Retainer, Gasket
	4449154	Screw
50	4451747	Cover, Back
	4449809	Screw
51		Trim, Bottom
	4448475	Black Model
	4448476	White Model
	4452414	Biscuit Model
	4159465	Screw
53	4449845	Support, Bracket
	4449809	Screw

FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

	4449315	Insulation, Wrap
	4450364	Insulation, Back

CONTROL PANEL PARTS

For Models:GBD277PDB7, GBD277PDQ7, GBD277PDS7, GBD277PDT7
(Black) (Designer White) (Black Stainless) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1		Control Panel Assy. W/Membrane, Switch
	8300433	Black Model
	8300434	White Model
	8300453	Black Stainless
	8300443	Biscuit Model
	3192690	Insulator, Membrane Switch
	8281179	Screw
2	4451033	Gasket, Control Panel
3	4452890	Microcomputer
	4449745	Screw

OVEN DOOR PARTS

For Models:GBD277PDB7, GBD277PDQ7, GBD277PDS7, GBD277PDT7
(Black) (Designer White) (Black Stainless) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1	4455617	Door Liner
3	4449253	Glass, Inner
4	4451721	Insulation, Door
5	4450813	Bracket, Handle
	4451040	Screw
7	4449257	Glass, Inner

Illus. No.	Part No.	DESCRIPTION
12		Door Glass, Assy
	4452062	Black Model
	4452063	White Model
	8300904	Biscuit Model
	4452478	Black, Stainless Model
13		Door Handle
	4448405	Black Model
	4448406	White Model
	8300255	Biscuit Model
14	4451668	Retainer, Glass
	4449809	Screw
19	4450361	Shield, Heat
	4449809	Screw
20	8300777	Retainer, Glass
	4449809	Screw

Illus. No.	Part No.	DESCRIPTION
23		Retainer, Clip
	4450863	Black Model
	4450864	White Model
	4452119	Biscuit Model
24		Hinge, Door
		White, Black & Biscuit Models
	8300569	Right Hand
	8300570	Left Hand
		Black Stainless Model
	8300571	Right Hand
	8300572	Left Hand
	4449743	Screw
25	4455256	Glass, Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models:GBD277PDB7, GBD277PDQ7, GBD277PDS7, GBD277PDT7
(Black) (Designer White) (Black Stainless) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
2	4452154	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
5	3181534	Rack, Roasting
6	4448715	Rack, Oven
7	4452153	Element, Bake
9	4451583	Motor, Convection
	4449154	Screw
10	4452226	Blade, Fan
12	4452227	Nut
21	4448988	Cover, Fan
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models:GBD277PDB7, GBD277PDQ7, GBD277PDS7, GBD277PDT7
(Black) (Designer White) (Black Stainless) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent−Top
3		Blower
	6610168	45MM Lower Oven
	4455334	60MM Upper Oven
	4455352	Bracket, Blower 60MM
	4449809	Screw

Illus. No.	Part No.	DESCRIPTION
4	4455177	Elbow, Vent−Bottom
5	8300642	Transformer, Control
6	4451789	Plate, Mounting
11	4449868	Block, Terminal
	3400080	Screw
13	4448548	Vent, (Control Panel)
	4450038	Screw
14		Side, Control Top
	4451597	Right
	4451598	Left
	4449809	Screw
	4449154	Screw

Illus. No.	Part No.	DESCRIPTION
15	4452244	Back, Control
	4449809	Screw
16	4450550	Cover, Top Rear
	4449809	Screw
17	4448664	Clamp
	4449809	Screw
18	4450553	Cover, Top Front
	4449809	Screw
20	4451758	Seal, Foam
21	4451985	Suppressor
	4452260	Spacer, Foam

OPTIONAL PARTS

For Models:GBD277PDB7, GBD277PDQ7, GBD277PDS7, GBD277PDT7
(Black) (Designer White) (Black Stainless) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
	261869	Cord Brown
	72032	Black
		PAINT, SPRAY
	350930	White
	261900	Citrine White
	830864	Black
		ADHESIVE
	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
		SPLICING WIRES−−25FT. LENGTH
	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
		WIRING HARNESS PARTS
	4451926	Harness, Wire (Latch)
	4450953	Conduit, Double
	4448664	Clamp
	4449809	Screw
	112432	Nut
	4450800	Screw, Ground
	4455737	Harness, Wire (Main)
	4452222	Spacer, Harness
	4454835	Tie, Cable
	4451761	Support, Wiring
	4454842	Tie, Cable
		Miscellaneous
	814381	Pin Hinge Kit
	4448950	Screw, Install (4)